

## ISTRUZIONI D'UTILIZZO OPERATION MANUAL:



Power source: This unit use one (1) "AAA" battery

Battery installation: Slide and open the battery compartment on the rear of the unit and insert one (1) AAA battery following the polarity diagram. NOTE: remove the clear film label over the LCD panel so LCD panel is visible.

Thermometer: Normal display shows Indoor and Outdoor temp in 1/10 degree.

**Per leggere la temperatura interna:** Spostare il selettore su "IN" per visualizzare la temperatura interna.

**Per leggere la temperatura esterna:** Spostare il selettore su "OUT" per visualizzare la temperatura esterna.

**Per selezionare la scala di lettura:** Selezionare "C" o "F" a seconda che si desideri la temperatura in gradi Centigradi o Fahrenheit.

**Per illuminare il display:** In ogni occasione è possibile visualizzare la temperatura. Al buio è sufficiente premere il pulsante "LIGHT" per illuminare il display.

**Dove installare il sensore:** Scegliere una posizione dove il sensore non sia esposto al calore del radiatore oppure in condizioni di utilizzo gravose (es. sotto il parafrangente). Una posizione ideale è dietro al paraurti anteriore, al riparo dal vento.

**To read indoor temperature:** Slide to IN (3) Switch to select INDOOR temperature display.

To read outdoor temperature: Slide to OUT (3) Switch to select OUTDOOR temperature display.

**To select C or F readout:** Slide Switch (2) to C or F position.

**Using the backlight:** You may check the temperature anytime in the dark by simply pressing LIGHT (1) button once. The display will light up with a soft glow that lasts for a while. NOTE: frequent use of this feature will affect battery life.

**To install the outside temperature sensor:** Remove the paper on the double-sided tape on the temperature sensor and stick onto the outside of a window. This sensor will monitor the outside temperature. Carefully route the wire inside and gently close the window.